

HIDfast

Recommends that the following fasteners are to be used with the following decking boards, to get the fastest and easiest installation possible.

Square edge, or grooved boards,

The following boards must be grooved on both sides,

*Wood,

Fastener

Cedar
Cypress **HF2.5, HF3, HF3W**
Fir
Mahogany (soft & medium density types)
Redwood
PUREWOOD, and other
thermally modified wood decking.

Wood,

Fastener

Batu
Garapa Gold **HF2.5, HF3, HF3W**
Teak,
and other similar
type hardwoods
Ipe
Ipe (that is very hard) **HF2.5WG**

*All PVC Decking,

HF2.5, HF3, HF3W

All Composites must be grooved

For 1/8" gap use - **HF2.5 or HF3**

For 1/4" gap use - **HF2.5WG or HF3W**

The New **HF2.5WG** has 1/4" spacer and a Black Oxide coating. **HF2.5WG** fasteners can be used on virtually all grooved decking.

* For an even easier installation, get boards grooved on one side, you can shoot a fastener through the square edge, and then slide the grooved edge under the second point.

Tool and Fasteners are **Not** recommended for CorrectDeck.

PT Decking, **Needs to be KDAT**, kiln dried after treatment.

HF2.5 - are 2.5" long and have special points on each end to make them the most versatile fastener. HF2.5 has a 1/8" spacer, to help gap boards. Fasten decking 1" thick or less.

HF3 - Is similar to HF2.5, but is 3" long. This fastener can be used on decking up to 1.5" thick.

HF3W - Is similar to HF3, but has a 1/4" spacer, and has been blackened.

HF2.5WG -Is designed for grooved Ipe, and Composites, it has 1/4" spacer, and is blackened.