

HIDfast,

September 29, 2009

Recommends the following decking types for the fastest and easiest installation possible.

Square edge, or grooved boards,

The following boards must be grooved on both sides,

*Wood,

Fastener

Cedar
Cypress **HF2.5 or HF3**
Fir
Mahogany*
Redwood

Wood,

Fastener

Batu
Garapa Gold **HF2.5 or HF3**
Ipe
Teak,
and other similar
type hardwoods

*PVC Decking,

AZEK
Cellek
ENDECK
Gossen Passport
Novation
SENSIBUILT
Trex Escapes **HF2.5 or HF3**
TRUEMARC
VEKA
XLM- TimberTech

Composite,

fiberon
Latitudes
MoistureShield **HF2.5 or HF3**
Timbertech
Trex

* For an even easier installation use boards grooved on one side, you can shoot a fastener through the square edge, and then slide the grooved edge under the second point.

Tool and Fasteners are Not recommended for CorrectDeck.

PT Decking, **Needs to be KDAT, kiln dried after treatment.**

